

Service Support Spirit

How to Set Speed Parameter for the -F2100B

Note: The speed parameters are factory set, and the parameters do not need to be adjusted;

Step 1: Turn on the machine power supply to enter the main interface of the system:



Step 2: Press F4[Setup] to enter the parameter setting interface;

Step 3: Press F5[System] to set those max speed parameters for the machine, and Press F8[Save] to save this change:

Service Support Spirit

Horizontal Axis Pulse	182.863	pulse/mm
Vertical Axis Pulse	182.863	pulse/mm
Max Cutting Speed	6000.000	mm/min
Max G00 Speed	6000.000	mm/min
Max Manual Speed	6000.000	mm/min
Small Arc Limit	500.000	mm/min
Limited Speed below Radius	4.00	mm
Accerate Time in Flame	0.40	s
Accerate Time in Plasma	0.20	s
Emergency Stop Time	0.080	s
Start Speed	250.000	mm/min
Max +X	100000.000	mm
Max +Y	100000.000	mm
Min -X	-100000.000	mm
Min -Y	-100000.000	mm
Chuck Pulse	149.250	
Chuck Max Spd	54.000	RPM

F1 Common	F2 Flame	F3 Plasma	F4 Mark	F5 System	F6 Import	F7 Export	F8 Save
--------------	-------------	--------------	------------	--------------	--------------	--------------	------------

Step 4: Press F1[Common] to set those practical speed parameters according to your instant needs, then press F8 to save this setting:

Max Cutting Speed	6000.000	mm/min
Manual Move Speed	1200.000	mm/min
G00 Move Speed	1000.000	mm/min
Demo/Back Speed	3000.000	mm/min
Marker Speed	3000.000	mm/min
Kerf Value	0.900	mm
Corner Speed(1-100)	30.000	%
Demo Run Speed	6000.000	mm/min
Cutting Type	Plasma	
System Mode	Pipe Cut	

F1 Common	F2 Flame	F3 Plasma	F4 Mark	F5 System	F6 Import	F7 Export	F8 Save
--------------	-------------	--------------	------------	--------------	--------------	--------------	------------