

## How to set the Torch Up/Dn Time—F2100S- THC

→ Problem: Set the Torch Up/Dn Time of the system, This parameter controls the rising and falling of the torch;

Problem analysis:

✳ 1. CNC system parameter setting;

**Solution:** Step 1- Main interface → Press F4 **【SETUP】** into Parameter interface → Press F4 **【PLASMA】** into Plasma interface as show pic1



Pic1

Step2: To set TORCHUP HIGH(M70) and TEMPO DESCENTE(M71):

TORCHUP HIGH(M70)=Set Value 02.00,

TEMPO DESCENTE(M71):Set Value 02.30

Press **【↓】** and **【↑】** to select the 4th row and change it into 02.00, Press **【ENTER】** go to the 5th row, change it into 02.30, Press **【ENTER】** , Press F7 **【GUAR/SAVE】** to save the whole setting, Press **【ESC】** back to the main interface.

Then have a trial cut and feedback.

