

How to solve THC screen appear A000 alarm—SDF-30A

→ Problem: When A000  appeared on the THC, means that the machine does not automatically adjustment function;


- Solution overview:
1. Plasma ARC+ and ARC- connection to the DIV PCB;
 2. The original arc voltage is out of range;
 3. The auto signal cable is in open circuit;
 4. DIV PCB is damaged;

Problem analysis:

- ✦ 1. Plasma ARC+ and ARC- connection to the DIV PCB;

Solution: Step 1- Check whether the positive and negative signals of the arc voltage of the machine are correspondingly connected with the positive and negative signals of the plasma arc voltage;

NOTE: The picture shows the position of the Hypertherm plasma arc voltage signal.



Service Support Spirit

Problem analysis:


✳ 2 The original arc voltage of the plasma power supply is out of range;

Solution: The normal output voltage of the original plasma arc voltage is 60V-165V, check the voltage with multimeter; otherwise the output of original arc voltage is wrong;

Check the connection arc DIV between the CNC system and the plasma power source, ARC+/ARC- should be connected with the original arc voltage of the plasma, if the connection is right, check the original voltage, if it is 60V--100V, it is good;

If it is out of range, Please contact your plasma supplier, determine the original arc voltage value of the plasma;

NOTE: The picture on the right is the location of the original arc voltage of Hypertherm plasma, for reference only.



Service Support Spirit


Problem analysis:

- * 3. The auto signal cable is in open circuit;

Solution: The signal from DIV PCB cannot be transmitted to the THC; Pin4 of the THC should be connected with the pin V of DIV PCB;

Check the connection with a multimeter

If disconnected, please connect pin4 of the THC with the pin V of DIV PCB as following:



Problem analysis:

- * 4. The DIV PCB is damaged;

Solution: When the plasma is arcing, use a multimeter to measure the voltage between the pin V and 24V- on the DIV PCB; this voltage is normally in the range of 1.2-3.3v;

Service Support Spirit

If there is no voltage value or exceeds a large range, it proves that the DIV PCB is bad and needs to be replaced.

